

#### INSTRUCTIONS

DFP1\*\*\*\*\*\*\*03

# DFP100 WITH REDUCED MINIMUM SETTING ON GND UNIT AND MINIMUM SETTING FOR UNDERVOLTAGE PICKUP

#### <u>Introduction</u>

These instructions, GEK-105580 together with GEK-105545, constitute the complete instructions for the DFP1\*\*\*\*\*\*\*\*03.

#### **Description**

This relay has the following differences from the standard relay described in GEK-105545:

The ranges of the TOC for GND has been changed to 0.010 - 0.12 amps RMS and the range for IOC and DEFINITE TIME has been changed to 0.010 - 1.60 amps rms. The setting range for UNDERVOLTAGE pickup has new range [5 -180]. The settings range for the OVERVOLTAGE pickup has new range [5-180].

These instructions do not purport to cover all details or variations in equipment nor provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company. To the extent required the products described herein meet applicable ANSI, IEEE and NEMA standards; but no such assurance is given with respect to local codes and ordinances because they vary greatly.

### **Calculations of Settings**

1. In the **Calculation of Settings** section of the GEK-105545 Instruction Book, replace the following items with the corresponding items in Table 3-1:

Table 3-1. DFP100 Relay Settings

CATEGORY	SETTING NAME	RANGE	INCREMENT	DEFAULT
TIME OVER-	DISABLE PHASE TOC	1 (YES)/0 (NO)		YES
CURRENT	CURVE PHASE TOC	1 (EXT INV)		3
{ SET }		2 (VERY INV.)		(INVERSE)
, ,		3 (INVERSE)		,
	PICKUP PHASE TOC	1.00 - 12.00	0.01 amps	1.00
	TIME DIAL PHASE TOC	0.5 -10.0	0.1	10.0
	DISABLE GROUND TOC	1 (YES)/ 0(NO)		YES
	CURVE GROUND TOC	1 (EXT INV		3 (INVERSE)
		2 (VERY INV.)		
		3 (INVERSE)		
	PICKUP GROUND TOC	0.01 - 0.12	0.01 amps	1.00
	TIME DIAL GROUND TOC	0.5 -10.0	0.1	10.0
DEFINITE TIME	DISABLE PHASE DT HIGH	1(YES)/0(NO)		YES
{ SET }	PICKUP PHASE DT HIGH	1.00 - 160.00	0.01 amps	1.00
	DELAY PHASE DT HIGH	0 - 100.00	0.01 seconds	0
	DISABLE PHASE DT LOW	1(YES)/0(NO)		YES
	PICKUP PHASE DT LOW	1.00 - 160.00	0.01 amps	1.00
	DELAY PHASE DT LOW	0 - 100.00	0.01 seconds	0
	DISABLE GROUND DT HIGH	1(YES)/0(NO)		YES
	PICKUP GROUND DT HIGH	0.01 - 1.60	0.01 amps	1.00
	DELAY GROUND DT HIGH	0 - 100.00	0.01 seconds	0
	DISABLE GROUND DT LOW	1(YES)/0(NO)		YES
	PICKUP GROUND DT LOW	0.01 - 1.60	0.01 amps	1.00
	DELAY GROUND DT LOW	0 - 100.00	0.01 seconds	0
INSTANTANEOUS	DISABLE PHASE INST. HIGH	1 (YES)/0 (NO)		YES
{ SET }	PICKUP PHASE INST. HIGH	1.00 - 160.00	0.01 amps	1.00
	DELAY PHASE INST. HIGH	0 - 2.00	0.01 seconds	0
	DISABLE PHASE INST. LOW	1 (YES)/0 (NO)		YES
	PICKUP PHASE INST. LOW	1.00 - 160.00	0.01 amps	1.00
	DELAY PHASE INST. LOW	0 - 2.00	0.01 seconds	0
	DISABLE GND INST. HIGH	1 (YES)/0 (NO)		YES
	PICKUP GND INST. HIGH	0.01 - 1.60	0.01 amps	1.00
	DELAY GND INST. HIGH	0 - 2.00	0.01 seconds	0
	DISABLE GND INST. LOW	1 (YES)/ 0 (NO)		YES
	PICKUP GND INST. LOW	0.01 - 1.60	0.01 amps	1.00
	DELAY GND INST. LOW	0 - 2.00	0.01 seconds	0

CATEGORY	SETTING NAME	RANGE	INCREMENT	DEFAULT
TORQUE CONTROL { SET }	GND TROE CNTRL SIGNAL	0(DISABLED) 1(EXTERNA) 2 (67N)		∩ (DISABLED)
	NEG. SEQUENCE LEVEL PH TRQE CNTRL SIGNAL	0.10 - 2.00 0(DISABLED) 1(EXTERNA)	0.01 A	1.0
	21PT SIGNAL	2 (21PT) 3 (27) 4 (50PL) 0(DISABLED) 1 (OR)		0
	21PT REACH	2 (AND) 0.05 - 50.00	0.01 ohms	0 5.00
	21PT ANGLE 59 OV PICKUP	10.0 - 90.0 5 - 180	0.1 degrees 0.01 volts	85.0 100
	27 UV PICKUP	5 - 180	0.01 volts	50
	59 TIME DELAY	0 - 240.00	0.01 seconds	0.20
	27 TIME DELAY	0 - 240.00	0.01 seconds	0.20

2. Replace the following paragraphs in the Time Overcurrent Settings section.

**Pickup Ground TOC -** This setting establishes the pickup level of the ground TOC function. The range is 0.01 - 0.12 amps RMS.

3. Replace the following paragraphs in the Definite Overcurrent Settings section.

**Pickup Ground DT HIGH -** This setting establishes the pickup level of the ground DT High function. The range is 0.01 - 1.60 amps RMS.

**Pickup Ground DT LOW -** This setting establishes the pickup level of the ground DT Low function. The range is 0.01 - 1.60 amps RMS.

4. Replace the following paragraphs in the Instantaneous Overcurrent settings section.

**Pickup Ground Inst. HIGH -** This setting establishes the pickup level of the Ground Inst. High function. The range is 0.01 - 1.60 amps RMS.

**Pickup Ground Inst. LOW -** This setting establishes the pickup level of the Ground Inst. Low function. The range is 0.01 - 1.60 amps RMS.

5. Replace the following paragraphs in the Torque Control Settings section.

**27 UV Pickup -** This setting establishes the pickup level of the Undervoltage unit. The range is 5.00 - 180.00 Vrms.

**59 OV Pickup -** This setting establishes the pickup level of the Overvoltage unit. The range is 5.00 - 180.00 Vrms.



## GE Power Management

215 Anderson Avenue Markham, Ontario L3R 1B3 Canada Telephone (905) 294-6222 www.GEindustrial.com/pm