






INSTRUCTIONS

GEK-22954

GP-100* **ADJUSTABLE SPEED DRIVE** 5-60HP, THREE PHASE



WARRANTY

GP-100 SCR DRIVE

The Company warrants to the original Purchaser for its own use that each new GP-100 SCR drive to be delivered hereunder will be free from defects in material, workmanship and title and will be of the kind and quality designated or described in the contract. The foregoing warranty is exclusive and in lieu of all other warranties whether written, oral or implied including any warranty of merchantability or fitness for purpose.

If it appears within one (1) year from date of original purchase for use that any part of the GP-100 SCR drive is defective in material or workmanship, and the Purchaser notifies the Company promptly, the Company shall thereupon correct any such defect, at its option, either by repairing any defective part or parts or by making available at the Company's plant, a repaired or replacement part.

NOTE: The Warranty is void if the conversion unit enclosure is removed or if the unit is tampered with in any way.


The conditions of any test shall be mutually agreed upon and the Company shall be notified of, and may be represented at, all tests that may be made. If requested by the Company, the Purchaser will ship any inoperative GP-100 unit (power conversion and regulator assembly), with shipping charges prepaid, to the Company at its plant at 1100 Lawrence Parkway, Erie, Pennsylvania 16501 and the Purchaser will ship any other defective part or parts of the GP-100 SCR drive, with shipping charges prepaid, to the plant, warehouse or service shop designated by the Company.

The liability of the Company to the Purchaser (except as to title) arising out of the supplying of the GP-100 SCR drive, or its use, whether on warranty, contract or negligence, shall not in any case exceed the cost of correcting defects or furnishing new or remanufactured parts as hereinabove provided, and upon the expiration of the warranty periods indicated above, all such liability shall terminate. The Company shall have no liability for any GP-100 SCR drive, or any part thereof, which becomes defective or inoperative because of improper application, or because of operation of the GP-100 SCR drive in excess of the Company's published ratings, or because of accident, misuse, abuse, or repairs or alterations on the part of the Purchaser or any third party other than the Company. The Company shall have no liability whatever under this warranty if the GP-100 SCR drive is operated with any drive motor other than the motor originally shipped by the Company for use with this equipment, and the Company shall have no liability for replacing any fuses which may fail for any reason. The Company shall not be responsible for, and shall not provide under this warranty, any installation services or adjustments for either original equipment or replacement equipment at the user's location. This warranty shall run only to the original Purchaser of the equipment for its own use and shall not be transferable to any other parties. The foregoing shall constitute the sole remedy of the Purchaser and the sole liability of the Company.

It is understood that the Company has the right to make changes in design at any time and that the Company reserves the right to replace assemblies or parts, pursuant to this warranty, with assemblies or parts which shall be functionally similar, but which may incorporate such changes in design, and that the Company shall not be responsible for any rewiring or other adjustments which may be necessary in order to accommodate such replacement assemblies or parts.

WARNING

SINCE HIGH VOLTAGES ARE PRESENT IN MANY LOCATIONS WITHIN THE SCR DRIVE, EXTREME CARE MUST BE EXERCISED IN THE SELECTION AND USE OF TEST INSTRUMENTS. WHETHER THE AC SUPPLY IS GROUNDED OR NOT, HIGH VOLTAGES TO GROUND WILL BE PRESENT AT MANY POINTS. OPERATORS SHOULD NOT STAND ON GROUNDED SURFACES OR BE IN CONTACT WITH GROUND WHEN APPLYING TEST INSTRUMENTS TO TEST POINTS. EXTREME CARE SHOULD BE TAKEN WHILE ATTEMPTING TO ADJUST, TROUBLESHOOT OR MAINTAIN ANY DRIVE SYSTEM DESCRIBED HEREIN.



GP-100*

ADJUSTABLE SPEED DRIVE

5-60HP, THREE PHASE


ERRATA SHEET: Affects GEK-22954
Pages 33 and 34

This errata sheet should be attached inside the front cover of GEK-22954 and retained as a part of this book.

The instruction book text should be changed in accordance with information contained in this errata sheet.

FIGURE 19 ELEMENTARY DIAGRAM — Page 33

On the elementary diagram add the dashed connection line ((P1A) to DRS (1)) and label and add note 16 after note 15 as indicated below:



16. On 460VAC drives a wire is connected from DRS (1) to 2TB (P1A).

SPARE AND RENEWAL PARTS — Page 34

In the "Conversion Unit" line under "Catalog Number" block, add as indicated below:

FROM: 331X232AB _ _ _


TO: 331X232 _ _ _ _ _
331X232 _ _ _ _ _

In the "Conversion Unit" line, to the right of "Part" add as indicated below:

FROM: "G01, G02, G03, G04, G05 and G06"

TO: ABG01, ABG02, ABG03, BAG04, BAG05 and BAG06.

* Trade-mark of General Electric Company.




GP-100*
ADJUSTABLE SPEED DRIVE
 5-60HP, THREE PHASE

ERRATA SHEET: FIGURE 19, PAGE 33

THE ERRATA SHEET SHOULD BE ATTACHED INSIDE THE FRONT COVER OF GEK-22954 AND RETAINED AS A PART OF THIS BOOK.


THIS PARTIAL CIRCUIT NOW APPEARS ON THE ELEMENTARY DIAGRAM, FIG. 19, PAGE 33.



* Trademark of General Electric Co., U.S.A

(OVER)

IN THE EVENT LOCAL CODES REQUIRE THE 115V AC CONTROL CIRCUIT BE GROUNDED, THEN CONNECT THESE COMPONENTS AS SHOWN BELOW:



REMOVE TWO WIRES EACH MARKED CPT-X1 FROM TERMINAL BOARD (X1) ON CPT TRANSFORMER.

REMOVE TWO WIRES EACH MARKED CPT-X FROM EITHER TERMINAL BOARD POINT (X2) OR (X3) ON CPT TRANSFORMER.

CONNECT THE TWO WIRES MARKED CPT-X1 TO EITHER TERMINAL BOARD POINT (X2) (50 HZ CONNECTION) OR (X3) (60 HZ CONNECTION) ON CPT TRANSFORMER, CHANGE THE WIRE NUMBER TO CPT-X.

CONNECT THE TWO WIRES MARKED CPT-X TO POINT CPT-X1 ON CPT TRANSFORMER AND CHANGE THE WIRE NUMBERS TO CPT-X1.

THESE CHANGES WILL ENABLE TRANSFORMER CPT TERMINAL X3 (60 HZ CONNECTION) OR X2 (50 HZ CONNECTION) ON CIRCUIT 24 TO BE GROUNDED IF THIS IS A REQUIREMENT OF A LOCAL CODE.

GENERAL ELECTRIC COMPANY - DIRECT CURRENT MOTOR & GENERATOR PRODUCTS DEPARTMENT
ERIE, PENNSYLVANIA 16531



PRINTED
IN
U.S.A.

CONTENTS

	Page
Warranty	2
Introduction / Receiving, Handling, and Storage / Maintenance	4
Description	7
Specifications	8
Installation Precautions / Installation	10
Interconnection	13
Setup and Adjustment	19
Operation	23
Troubleshooting	24
How the SCR Drive Works	28
Appendix	32

LIST OF ILLUSTRATIONS

Figure		Page
1,2	Power Units	5,6
3	Interconnection of SCR Drive	14
4,5	Enclosures	14
6	Interconnection of Operator Stations	16
7	Operator Station	17
8	Tachometer Feedback Modification	17
9	Voltage Follower Modification	18
10,11	Conversion Units	22
12	Rectifier Bridge Schematic	28
13	Typical Waveforms	28
14	Regulator Block Diagram	30
15	Power Unit Dimensions	32
16,17	Speed Indicator Dimensions	32
18	Operator's Station Dimensions	32
19	Elementary Diagram	33
20	Transformer Connection Diagrams	35
21	Oscilloscope Trace After Adjustment	36

LIST OF TABLES

Table		Page
I	Interconnection Chart	15
II	Power Unit Rating Data	15
III	Voltage Check List	24
IV	Troubleshooting Chart	25
V	Spare and Renewal Parts List	34
VI	Transformer Data	35

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

INTRODUCTION

This instruction manual is a guide to the installation, setup, operation, maintenance and troubleshooting for the SCR drive.

If any modifications or special applications are required other than those covered in this instruction book, please contact the General Electric Company prior to implementation to preclude faulty operation or misapplication of the equipment. Failure to do so could nullify your warranty. (See Warranty Statement)

This equipment has been factory tested and adjusted so as to require only minor adjustment during installation and set-up. Should further information be desired or should a particular problem arise which is not covered sufficiently for the purchaser's purpose, the matter should be referred to the General Electric Company, Speed Variator Products Department, Erie, Pennsylvania.

RECEIVING, HANDLING, AND STORAGE

RECEIVING

Place the equipment under adequate cover immediately upon receipt. The packing cases are NOT suitable for out-of-doors or unprotected storage. Examine each shipment carefully on its arrival and check it against the packing list. Promptly report any shortage or damage incurred in shipping to the carrier and to the nearest Industrial Equipment sales office of the General Electric Company.

HANDLING

The SCR drive can be transported by lift trucks with forks completely under the base of the packing case.

STORAGE

If the equipment is not to be installed immediately, store it under cover in a clean, dry location away from any

area where construction work is in progress, and protect the equipment from low temperatures and rapid or extreme variations in temperature or humidity. Take care to prevent the accumulation of moisture, dust, or dirt in the equipment during storage or installation, since these contaminants are detrimental to the equipment insulation.

This equipment may be stored at ambient temperature of -20 C to 70 C for a period of up to one year. Air must be free of chemical and electrically conductive contaminants, and other conditions must be such that no moisture condensation occurs in or on the equipment.

In addition, when a control that has been in operation and will be shutdown for either a short or extended period of time, it is recommended the environmental conditions be maintained the same as when in operation. Power supplies, ventilation or heating, and air conditioning (if used) should be left on during the downtime to prevent large changes in temperature and possible moisture condensation.

MAINTENANCE

Maintenance of the SCR drive is primarily a matter of periodic inspection and cleaning of the three drive components; the power unit, motor, and operator's station.

After removing the a-c power, clean the exterior and interior of the power unit by vacuuming or blowing accumulated dust and dirt. Do not use a high-pressure air hose, as this may damage the electrical components.

Check all electrical connections for tightness and examine the electrical contacts on the contactors. Both copper and silver contacts discolor and become roughened

during normal operation. Generally, contacts will not require attention but, if prominent beads form, due to severe arcing, dress the contact face with a fine file. Do not use sandpaper or emery cloth, and never oil any part of the power unit.

Keep the outside of the operator's station free from grease and dirt, and do not oil the devices.

Motor ventilation openings must be kept free of dirt to allow adequate ventilation. Refer to the motor instruction book for lubrication recommendations.




Fig. 1. Small Cabinet
 (15HP, 230VAC Power Unit
 with All Modifications Shown)




Fig. 2. Large Cabinet

**(60HP, 460VAC Power Unit
with All Modifications Shown)**

DESCRIPTION

BASIC DRIVES

The DC3032 SCR Adjustable-Speed Drive is a packaged, all-electric-drive, operated from three phase a-c power. The drive consists of:

1. A wall-mounted power unit which contains the conversion unit, necessary magnetic contactors, relays, and resistors. The unit provides conversion of incoming a-c power to d-c power, as well as necessary regulator functions.

2. An adjustable-speed d-c drive motor.

3. An operator's station which contains the speed-setting potentiometer and the necessary operating push-buttons.

The conversion unit is the control center of the drive. This unit contains two heat sinks on which are mounted the SCRs and diode rectifiers. The heat sinks support three printed circuit boards containing the protective, firing, and regulating circuits which control the SCRs (which in turn control the speed of the d-c motor). The conversion unit is open at the bottom and top to allow proper ventilation. Forced ventilation is provided for drives rated 20 HP and above at 230 VAC and 40 HP and above at 460 VAC. In addition, all 460 VAC conversion units will contain side mounted transformers (STA) and various circuit protective devices. Four potentiometers which control the setting of zero speed, IR compensation, acceleration time and current limit, are mounted in the conversion unit. The control knobs for these potentiometers are located on the front of the conversion unit so that they can be adjusted while the unit is operating. These potentiometers are labeled ZERO ADJ, IR COMP, TIME ACCEL, and CUR LIMIT. The conversion unit also contains a phase-sequence indicating light. The a-c supply fuses are mounted behind the conversion unit cover for drives rated 5–15 HP at 230 VAC. Panel mounted fuses are supplied for all other ratings. The warranty is void if the unit is tampered with in any way (see WARRANTY).

The operator's station will contain a maximum of five controls:

1. Speed Control Potentiometer,
 2. Start Pushbutton,
 3. Stop Pushbutton,
 4. Run-Jog Switch,
 5. Forward-Reverse Switch,
- of which 1–4 are included in the basic drive.

MODIFICATIONS

Tachometer Feedback

If improved speed regulation is ordered, the tachometer-feedback unit will be shipped with the power unit. Connection of only four leads is done at time of installation. Complete instructions are included under INSTALLATION.

Jog (Deletion)

If jog is deleted, the run-jog switch will be omitted from the operator's station.

Dynamic Braking (DB)

If dynamic braking is ordered, the braking resistor and related power wiring will be supplied as an integral part of the power unit.

Reversing (Selective Rotation) with Dynamic Braking (DB)

Anti-plugging protection, forward-reverse contactors and dynamic braking are provided, when ordered, as an integral part of the power unit. Direction may be selected before starting with the forward-reverse switch mounted on the operator's station.

Line Transformer

If a transformer is ordered it will be shipped separately for mounting and wiring by the purchaser. Transformer ratings, catalog numbers and connection diagrams are included in the APPENDIX.

SPECIFICATIONS

BASIC DRIVES

Power Supply

Voltage — 230VAC, -5 +10%, 3 Phase
 or 460VAC, -5 +10%, 3 Phase

Frequency — 60Hertz \pm 1Hertz
 (50 hz special orders).

Speed vs Torque

Typical data for speed versus torque is shown below:

Motor Enclosure	Percent Rated Speed			
	100-60	50	40	5
	Percent Continuous Torque (Or Rated Amps)			
DP	100	94	87	45
TE	100	95	92	82

NOTE

THE VALUES TABULATED REPRESENT AN AVERAGE FOR 5 TO 60HP MOTORS. IF CONTINUOUS TORQUE GREATER THAN THAT LISTED IN THE TABLE IS REQUIRED, SUPPLEMENTARY VENTILATION OR A DERATED MOTOR MAY BE REQUIRED. REFER TO THE COMPANY FOR SPECIFIC DATA OR RECOMMENDATION.

Speed Regulation

The speed regulation is five percent of motor base speed for a 95-percent load change over the 20/1 speed range (with optimum adjustment of IR compensation by the purchaser). Speed regulation is specified under steady-state conditions and with constant line voltage, frequency, and ambient temperature.

Steady-state motor speed may also be affected by changes in line voltage, frequency, and ambient temperature. These variables (other than load) are referred to as "service deviations".

Specified performance does not apply to transient changes in load or ambient conditions, not when connected-load inertia is in excess of twice motor inertia (referred to the motor shaft). See the motor dimension sheet for inertias.

Variable	Change	Speed Change in Percent of Rated
Voltage	-5, +10%	} 15%
Frequency	2%	
Ambient Temp	15C	

Acceleration Control

Adjustable Time

Total accelerating time (to full speed) is adjustable from 2.5 - 10 seconds. This complete time range is only available when 150-percent rated torque is sufficient to accelerate the drive and load to rated speed in 2.5 seconds or less — Modifications by adding special capacitors.

Decelerating time (when preset speed is reduced) is at a fixed rate of three seconds. If normal coasting time exceeds three seconds, the load characteristics determine deceleration time.

Current Limit

Adjustable from 80-150-percent rated current. Timing may be set at minimum (or disabled) and current limit used to control accelerating (and running) torque - or the current limit may be used with timed acceleration, providing a maximum current (torque) limit.

Protection

Current-Limiting Fuses — Provide short-circuit protection for the power unit and purchaser's wiring in the event of rectifier failure or control-circuit shorts.

Static IOC — An internal circuit providing d-c fault-current protection for the motor and power unit.

Current Limit — Limits operating overloads to 150-percent rated (or less as adjusted) for protection of motor and power unit, (see "Overload" on Page 9).

Under voltage — A-c operated d-c line contactor protects against automatic restarting following a-c power interruption.

Phase Sequence — Indicating light "on" for correct sequence.

Loss of Phase Protection — Provides system shutdown upon loss of one or more phases.

Thermal Switches — Provide system shutdown for high temperatures. (heatsink and motor).

Control Power Transformer — Fused 115VAC control supply.

Dynamic Braking

When dynamic braking is provided, the drive system shall be capable of braking a load (whose inertia equals that of the motor) at an initial current of 150 percent of rated armature current from full speed to standstill three times in rapid succession with the dynamic braking resistor initially at ambient temperature.

Efficiency

The efficiency (a-c to d-c) of the SCR conversion unit is approximately 97 percent at full load, full speed, and is high even at light load, low speed. The over-all drive efficiency is the product of the conversion and motor efficiency, or approximately 80 percent.

Power Factor

The SCR drive power factor is approximately 75 percent at full load, full speed, and is reduced with speed.

Service Factor

The service factor is 1.0.

Overload

150 percent of rated motor torque, one minute maximum.

Minimum Load

Five percent rated power-unit current.

Drive will generally operate satisfactorily without load coupled to the motor because motor losses approximate five percent current.

Service Conditions

Ambient temperature of 10C to 40C (50F to 104F).

Altitude — sea level to 3,300 feet.

Cooling

Forced cooling is provided for 20–30HP, 230VAC and 40–60HP, 460VAC drives. All others are convection cooled. All Nema 12 applications require forced cooling (fan).

Jog

Jog is at an independent, preset speed, adjustable from 1/10 — 1/3 rated speed.

MODIFICATIONS

Improved Speed Regulation (Tachometer Feedback)

When this modification is ordered providing an a-c tachometer and the tachometer-feedback unit for the power unit, speed regulation may be improved as follows.

Speed regulation — One percent of motor base speed for a 95 percent load change — over a 30/1 speed range. Speed change due to service deviations (see page 8) is improved to three percent.

INSTALLATION PRECAUTIONS

VOLTAGE TRANSIENTS

In order to obtain maximum reliability and life from your SCR Drive, there are certain precautions that should be followed during the application, installation, and use of this equipment.

When silicon rectifiers (diodes) and silicon controlled rectifiers (SCRs) are subjected to voltage transients (spikes) in excess of their maximum rating, even for extremely short periods of time, they are apt to be permanently damaged. Destructive voltage transients (in excess of those for which the drive is protected) may be produced by interrupting relay coils, brake-solenoid coils, transformer primaries and other inductive electrical devices.

To ensure maximum protection of the SCR Drive, the following practices should be followed:

1. Always stop the SCR Drive by opening the d-c armature loop first (drive stop pushbutton) before disconnecting the drive from the a-c line.
2. Do not switch associated power or control-

transformer primaries while the SCR Drive is operating (see No. 1 above).

3. Avoid switching transformers and other heavy loads on the a-c line while the SCR Drive is operating (see No. 1 above).

4. Do not run SCR Drive interconnecting wires in the same conduit runs or in close proximity to other control equipment wires.

5. Use a control transformer to supply a-c power to auxiliary relays and devices.

6. If external magnetic devices are used to control the magnetic circuit of the SCR Drive, use an RC suppression circuit (47-ohm, 2-watt, molded composition resistor connected in series with a 0.25 mfd, 600-volt, d-c capacitor) connected directly across the coil of each device.

For a particular application, some of the steps listed above may not be necessary. Also, where extensive relaying is proposed, additional problems may be encountered. It is suggested that a sketch or drawing of the proposed circuits be sent to the General Electric Company for recommendations.

INSTALLATION

GENERAL

Location and mounting of the SCR drive components is described in this section. When the equipment is installed, check all accessible factory-made connections for tightness, since connections may become loose during shipping or storage.

NOTE

ALL MODIFICATION KITS ORDERED SHOULD BE INSTALLED PRIOR TO MOUNTING THE POWER UNIT.

POWER UNIT

Two enclosures are available for the power unit, depending on the rating of the drive. Refer to "Dimensions" in the Appendix for outline dimensions.

Location

The SCR drive power unit is suitable for use in most factory areas where other industrial equipment is installed. Install the power unit in a well ventilated area which is not subject to ambient temperatures above 40 C (104 F). Avoid locations subject to steam vapors, oil vapors, chemical fumes, excessive moisture, or excessive dirt, dust, or lint.

If the power unit is used with a motor suitable for hazardous locations, install the power unit away from the hazardous area. Make sure that there is clearance around the outside of the enclosure to allow a normal flow of cooling air.

WARNING

NEVER INSTALL THE UNITS WHERE HAZARDOUS, INFLAMMABLE OR COMBUSTIBLE VAPORS OR DUST ARE PRESENT.

Mounting

Mount the power-unit enclosure on any firm, reasonable flat, vertical surface, by means of the mounting holes at the top and bottom of the enclosure. The mounting holes are suitable for 3/8 inch mounting bolts and flat washers (the use of four bolts per enclosure is recommended).

Conduit Entrance

Conduit entrance can be made through the top or bottom of the power unit enclosure. Refer to Fig. 3, page 14 for recommended conduit runs and entries.

All external power connections are made to terminal boards located near the top of the enclosure. The external control connections are made to terminal boards located near the bottom of the enclosure.

OPERATOR STATION

The operator's station must be disassembled for mounting and wiring. First, remove the two screws securing the cover to the operator's station enclosure and then remove the cover (with the control devices mounted on the cover) from the enclosure. See Fig. 7, page 17.

For convenience and ease of wiring, a pictorial wiring decal is provided on the back of the front cover plate that coincides with the group number ordered. All external wiring must be connected as the decal indicates.

Location

The SCR drive operator's station is suitable for use in most factory areas and should be located in a position most convenient for the machine operator. Avoid locations subject to steam vapors, oil vapors, chemical fumes, excessive moisture, or excessive dirt, dust, or lint.

WARNING

NEVER INSTALL THE OPERATOR'S STATION WHERE HAZARDOUS, INFLAMMABLE, OR COMBUSTIBLE VAPORS OR DUSTS ARE PRESENT.

The operator's station should be in a position which is convenient for the machine operator.

Conduit Entrance

The knock-out plug in the operator's station enclosure may accept conduit from either the top or bottom by rotation of the enclosure.

When using either rigid or thin-wall conduits, it is generally easier to attach the unit to the end of the conduit before locating and installing the mounting screws.

Mounting

Mount the back of the operator's station in the desired location on any firm, reasonably flat surface, by means of the mounting holes provided. The mounting holes are suitable for either wood screws or No. 10 machine screws.

DC MOTOR

A separate instruction book is provided giving information on location, conduit entrance and mounting of the d-c motor. The motor should be mounted on the driven machine (or as appropriate for the installation) before proceeding with wiring, setup, and adjustment.

Do not couple the motor to the load until after preliminary setup instructions have been completed.

POWER UNIT MODIFICATIONS

Tachometer Feedback Kit

Mount the kit as shown in Fig. 8 page 17, terminating the four numbered leads (from the tachometer kit) as identically numbered terminal points (9, 10, 13 and 28) on 1TB. Remove the jumper between points 9 and 10 on 2TB.

FOLLOWER DRIVE MODIFICATION

Follower Voltage Signal

The following voltage signal required by the SCR drive is 5 ma at 20 volts d-c, maximum. If the follower source voltage is higher than 20, a two-watt series resistor

must be added and separately mounted by the purchaser. The value of this resistance may be determined as follows:

Series Resistance (Ohms)=(Signal Voltage - 20) x 200

The maximum follower-signal voltage permissible is 250 volts d-c. This signal must have less than 1.0 percent a-c rms ripple. An armature voltage signal from a rectifier drive is not an acceptable follower signal without adequate filtering and isolation.

The follower signal must be isolated from the a-c

line or, alternately, the SCR drive must be equipped with a line isolating transformer.

Refer to Fig. 9, page 18 for interconnection information.

Removal of Timed Acceleration

Since timed acceleration is generally not desirable on follower drives, it should be removed (see note 2 on Fig. 19, page 33) and the time acceleration control turned to a maximum setting.

INTERCONNECTION

GENERAL

All internal electrical connections between devices in the power unit have been made at the General Electric factory, except connections for the tachometer-feedback-unit modification, since this component is shipped separately for installation by the purchaser.

REFER TO PAGE 10, "INSTALLATION PRECAUTIONS" BEFORE INSTALLING INTERCONNECTION WIRING.

INTERCONNECTION OF DRIVE COMPONENTS

Electrical interconnections are required between the power unit and motor and between the power unit and operator's station, as shown on Fig. 3, page 14. Figure 3 shows the conduit runs required for these interconnections. Table I, page 15 shows the number of wires required for each conduit run as shown in Fig. 3. Wire sizes for interconnections should be selected in accordance with the ampere requirements shown in Table II, and in accordance with local and national electrical codes.

Proceed to install conduit runs 1 through 3 in accordance with this tabulation.

GROUNDING

No part of the a-c or d-c electrical circuit may be grounded unless a line isolating transformer is used on the a-c input, and then only at one point. If a follower voltage is used and is not isolated from the a-c line, the SCR drive must be equipped with a line isolating transformer.

It is recommended that the power unit, operator's station, and d-c motor enclosures be grounded in accordance with NEC or local code requirements.

AC POWER CONNECTION

1. Make certain that the input voltage and frequency of the available power supply agree with the rating on the power-unit nameplate located on the inside of the power-unit enclosure. If an a-c line transformer is to be used, refer to step 4.

2. Electrical codes generally require the use of a fused disconnecting switch or circuit breaker in the a-c power line ahead of the SCR drive and transformer (if used). This disconnecting device also provides a convenient method of removing field excitation from the d-c motor when the drive is not in use, and allows complete removal of power for routine maintenance and inspection. The disconnecting switch and fuse (or circuit breaker) should be selected in accordance with the national electrical code and/or local code requirements based on the power input data on the SCR drive nameplate. This data is summarized in Table II, page 15 to aid in the selection of disconnecting devices, fuses, and wire sizes.

3. A-c power connection from the disconnecting device to the power unit may now be made in accordance with conduit run 3 as shown in Table I.

4. If the available power supply is other than that shown on the power unit data nameplate, it will be necessary to use a line transformer between the disconnecting device and the power unit. This transformer will be separately mounted by the purchaser. The appendix provides complete information on both auto and isolating transformers for use with SCR drives, including required kva, dimensions, connections, and catalog numbers.

FINAL CHECK

After all electrical connections have been made, complete the installation as follows:

1. Recheck all connections, using the Interconnection Chart, Table I, page 15. Recheck the transformer connections (if used) and connections to the disconnecting device (if used).

2. Reassemble the operator's station. Carefully dress the interconnecting wire into the back of the station so that the device assembly may be installed. Keep the wires away from sharp edges and do not force the device assembly into place. Replace the station cover.

3. Recheck the motor connections, carefully tape, and insert them in the conduit box. Replace the conduit-box cover.

4. Install protective fuses in the a-c disconnect (if used).




Fig. 3. Interconnection of SCR Drive

- NOTES:
1. DRAWING NOT DRAWN TO SCALE.
 2. REFER TO FIG. 15, PAGE 32 FOR RECOMMENDED CONDUIT ENTRANCES.




Fig. 4. W20 Enclosure
(15HP, 230V Power Unit Shown)




Fig. 5. W25 Enclosure
(60HP, 460V Power Unit Shown)

TABLE I
INTERCONNECTION CHART

Conduit or Route Number	Description	Wire No.	Connection Points *		Remarks
			From Power Unit	To	
3 ↓	3 Phase AC Line Supply	L1 L2 L3	L1 L2 L3	AC Phase 1 ↓ 2 3	
2 ↓ ↓ ↓ ↓	Adjustable DC Voltage Output	A1 A2	PTB(A1) PTB(A2)	DC Motor A1 ↓ A2	Insulate all Motor Connections with PVC Tape
	DC Motor Series Fld (when used)	S1 S2	PTB(S1) PTB(S2) Remove Jumper PTB(S1, S2)	S1 ↓ S2	The Series Field may be wired in at the Motor Conduit Box for <u>Non-Reversing Drives</u> only by Connecting wire S1 to A2 and bringing S2 back to PTB(2) in the power unit.
	DC Motor Thermal Sw (when used)	11 12	1TB(11) 1TB(12)	P2 ↓ P1	When Motor Thermal Switch is used remove Jumper between 1TB(11) and 1TB(12).
	DC Motor Shunt Fld	18 19	1TB(18) 1TB(19)	F1 ↓ F2	
4 ↓	Tachometer	9 10	1TB(9) 1TB(10)	Tach Feedback ↓	+ if using DC Tach - if using DC Tach
1 ↓	Operator Station		Refer to Page 16 for Operator Station Interconnection Information		

* Explanation of Termination Nomenclature:


1. When designated as (example) PTB(A1), PTB implies terminal board P, and A1 is the connecting point on that terminal board.
2. All nomenclature not preceded by the letters TB are located on devices.

NOTE: FOR APPROPRIATE WIRE SIZE INFORMATION, CONSULT LOCAL AND NATIONAL CODES AND REFER TO TABLE II FOR AMPERE RATINGS.


TABLE II POWER UNIT RATING DATA

AC Line Volts	230							460									
	5	7½	10	15	20	25	30	5	7½	10	15	20	25	30	40	50	60
Horsepower (HP)																	
Typical Motor Sh Fld Amps	1.0	1.0	1.5	1.5	1.5	1.7	1.4	1.0	1.3	1.5	1.7	2.0	2.0	2.0	1.7	2.5	1.7
† Typical DC Line Amps	21	28	36	54	71	91	107	9	14	18	26	35	42	50	68	84	101
† Typical AC Line Amps	20	26	34	50	65	84	98	9	14	18	25	34	40	47	63	78	93

† Rated at 100% load




WIRE NO	CONNECTION POINTS	
	FROM POWER UNIT	TO OPERATOR STATION
3	1TB(3)	2PB(3)
4	1TB(4)	2PB(1)
7	1TB(7)	TB(2)
12	1TB(12)	1PB(1)
13	1TB(13)	TB(1)
41	1TB(8)	TB(3)




WIRE NO	CONNECTION POINTS	
	FROM POWER UNIT	TO OPERATOR STATION
3	1TB(3)	2PB(3)
4	1TB(4)	1SW(2)
7	1TB(7)	TB(2)
12	1TB(12)	1PB(1)
13	1TB(13)	TB(1)
14	1TB(14)	1SW(6)
41	1TB(8)	TB(3)

NON-REVERSING

NON-REVERSING WITH JOG



WIRE NO	CONNECTION POINTS	
	FROM POWER UNIT	TO OPERATOR STATION
1	1TB(1)	2SW(4)
2	1TB(2)	2SW(5)
3	1TB(3)	2PB(3)
4	1TB(4)	2SW(1)
5	1TB(5)	2SW(6)
6	1TB(6)	2SW(3)
7	1TB(7)	TB(2)
12	1TB(12)	1PB(1)
13	1TB(13)	TB(1)
41	1TB(8)	TB(3)



WIRE NO	CONNECTION POINTS	
	FROM POWER UNIT	TO OPERATOR STATION
1	1TB(1)	2SW(4)
2	1TB(2)	2SW(5)
3	1TB(3)	2PB(3)
4	1TB(4)	2SW(1)
5	1TB(5)	2SW(6)
6	1TB(6)	2SW(3)
7	1TB(7)	TB(2)
12	1TB(12)	1PB(1)
13	1TB(13)	TB(1)
14	1TB(14)	1SW(6)
41	1TB(8)	TB(3)

REVERSING

REVERSING WITH JOG

Fig. 6. Interconnection of Operator's Stations





Fig. 7. Operator Station (all options shown)




Mount the tachometer feedback kit as indicated in the photo and terminate the four leads as follows:

Wire No.	Connect To	Remarks
9	1TB(9)	Tach Input
10	1TB(10)	Tach Input
13	1TB(13)	Kit Output (Common)
28	1TB(28)	Kit Output

Remove the metal jumper from 2TB(9) to 2TB(10).

When using a DC tachometer, verify that the tach connection to 1TB(9) is of a positive (+) polarity (DC) when the motor is rotating in the desired direction.

Fig. 8. Tachometer Feedback Modification



1. Calculate value of series resistance (page 12) and add to circuit.
2. Connect voltage follower leads as shown at the left (bottom).
3. Disconnect wire 40 from jog kit terminal board and insulate with tape.
4. Remove metal jumper from 2TB(4, 4A). (Removing time acceleration).




Fig. 9. Voltage Follower Modification

(Top: wire 40 removed, Bottom: voltage follower circuit connection)

SETUP AND ADJUSTMENT

SETUP INSTRUMENTS AND TOOLS

A 500 volt, d-c voltmeter and a screwdriver will suffice to set up and adjust this SCR drive. However, if optimum drive performance is required, it is recommended that a hand tachometer and a d-c ammeter of appropriate rating also be available. The required ammeter rating may be determined from the tabulation of d-c motor current in Table II, page 15.

PRELIMINARY

1. Open the front door of the power unit enclosure. Check to see that motor is not coupled to the load and is free to rotate.
2. Connect the voltmeter across the d-c armature at points A1 and A2. Point A1 is positive.
3. Connect the ammeter (if used) to points P2 and S2 on PTB, removing the metal jumper.
4. Close the incoming line to the power unit.
5. If phase sequence light is not "on", remove power and interchange any two a-c power leads.

WARNING

THIS EQUIPMENT IS AT LINE VOLTAGE ANY TIME THE INCOMING LINE IS CLOSED, WHETHER THE UNIT IS IN OPERATION OR NOT IN OPERATION. AC POWER MUST BE DISCONNECTED (ALL AC LINES) FROM THE POWER UNIT BEFORE IT IS SAFE TO TOUCH ANY INTERNAL PARTS OF THIS EQUIPMENT.

SPEED RANGE (MOTOR NOT COUPLED TO MACHINE)

NOTE: IF THE TACHOMETER-FEEDBACK MODIFICATION HAS BEEN ORDERED, OMIT THIS PROCEDURE AND SUBSTITUTE "TACHOMETER FEEDBACK" PAGE 21.

To adjust the speed range of the drive complete the following steps:

1. Set the SPEED potentiometer on the operator's station to zero.
2. Depress and release the START pushbutton.
3. Adjust the minimum speed (by means of the

ZERO ADJ potentiometer on the conversion unit) so that the motor just turns over.

4. Back off the minimum speed setting until the motor just stops.
5. Turn the SPEED potentiometer on the operator's station to 100 percent (full CW) and observe the d-c armature voltage on the voltmeter. This voltage should be approximately 220 VDC for a 230 VAC drive and approximately 460 VDC for a 460 VAC drive with no load on the motor.
6. If this voltage is not correct, use a screwdriver to adjust the MAX SPEED rheostat until the d-c armature voltage is within the required limits. Turning the rheostat shaft clockwise increases armature voltage and speed.
7. Depress and release the STOP pushbutton.
8. If the direction of motor rotation is not correct, remove a-c power, and then interchange motor armature leads at the power-unit terminal-board (PTB) points A1 and A2.

TIMED ACCELERATION (MOTOR NOT COUPLED TO MACHINE)

An adjustable, timed-acceleration circuit is provided as standard equipment on all SCR drives. The time required to accelerate from standstill to top rated speed is continuously adjustable from approximately 2.5 to 10 seconds.

Set the desired acceleration time by adjusting the TIME ACCEL potentiometer located on the front of the conversion unit. Turning this potentiometer clockwise increases the acceleration time. It may be necessary to re-adjust the MAX SPEED potentiometer in the power unit after the acceleration time has been set.

The SCR drive also provides fixed timed deceleration. With the drive running at rated (preset) speed, if the operator's speed-control potentiometer is quickly turned to a lower speed (or to zero), the drive will decelerate to this new speed in three to four seconds, assuming that the coasting time of the drive (and load) is less than three seconds. It follows that, if the load has high inertia and a long coast time, the decelerating time will be longer than three seconds as determined by the load inertia.

If timed acceleration is not desired for any reason, disable the timed acceleration circuit by removing the jumper between points 4 and 4A on 2TB, and turn the TIME ACCEL potentiometer to maximum.

CURRENT LIMIT (MOTOR COUPLED TO LOAD)

A current-limit circuit is standard on all SCR drives. This circuit provides protection against excessive armature current and overload during acceleration and normal operation. The current limit is adjustable from approximately 80 percent to 150 percent of the rated armature current by means of the CUR LIMIT potentiometer located on the front of the conversion unit.

CAUTION

UNDER NO CONDITIONS SHOULD THIS EQUIPMENT BE OPERATED IN EXCESS OF 150 PERCENT RATED ARMATURE CURRENT. FAILURE TO OBSERVE THIS LIMIT MAY RESULT IN OPENING OF THE LINE FUSE OR PERMANENT DAMAGE TO THE SCR'S AND POWER RECTIFIERS.

Normally the current limit is set at 150 percent rated current. However, current limit can also be used to control acceleration of the motor, and maximum accelerating torque can be adjusted between 80 and 150 percent rated. Adjust the current limit to the desired value by means of the CUR LIMIT potentiometer located on the front of the conversion unit. Turning this potentiometer clockwise increases the current limit setting from approximately 80 to 150 percent of rated armature current.

IR COMPENSATION (MOTOR COUPLED TO LOAD)

NOTE

IF TACHOMETER FEEDBACK HAS BEEN ORDERED, OMIT THIS PROCEDURE.

Simplified Adjustment

The simplified adjustment of IR compensation is recommended where any one or more of the following conditions may exist.

1. It is difficult or impossible to change the driven machine load during the setup procedure.

2. Where machine load does not change significantly.

3. Where speed regulation (due to load change) of 5–10 percent is acceptable.

The simplified adjustment of IR compensation is made by simply setting the IR COMP potentiometer on the conversion unit at a setting of 1 to 3.

If optimized adjustment of the IR compensation is required, set as indicated and proceed to the next step.

Optimized Adjustment

1. Start the drive by momentarily depressing the START button.

2. Turn the SPEED potentiometer so that the motor is rotating at approximately half rated speed.

3. Adjust the driven machine for minimum load conditions. The value should not be less than five percent of rated current for smooth operation.

4. Read and record the motor speed by using a hand tachometer. Motor speed may be conveniently read by removing the dust cap on the commutator end motor bearing.

5. Adjust the driven machine for maximum load (not exceeding 100 percent rated torque), and again read motor speed by using the hand tachometer.

6. If the "maximum-load" speed is less than the "minimum-load" speed, turn the IR COMP potentiometer on the conversion unit clockwise until they are equal.

7. Repeat Steps 3, 4, 5 and 6.

8. Turn the SPEED potentiometer to its maximum clockwise position and readjust the MAX SPEED potentiometer in the power unit, so that the motor is running at the maximum speed required for the application, but not in excess of the rated speed on the motor nameplate.

Jog (Motor Coupled to Load)

1. Place the RUN-JOG switch on the operator's station to the JOG position and verify that the SPEED potentiometer is set at zero.

2. Depress and hold the **START** pushbutton and, at the same time, use a screwdriver to adjust the **JOG SPEED** potentiometer to the desired jog speed. Turning the potentiometer shaft clockwise increases the jog speed.

3. Release the **START** pushbutton.

MODIFICATIONS

Refer to the interconnection section for modification wiring and installation information.

Tachometer Feedback
(Motor Not Coupled to Load)

NOTE

FOLLOW THIS PROCEDURE ONLY IF THE IMPROVED SPEED-REGULATION MODIFICATION (TACHOMETER FEEDBACK) HAS BEEN ORDERED.

WARNING

EXCESSIVE SPEED CAN CAUSE DAMAGE TO MOTORS AND SERIOUS INJURY TO PERSONNEL.

BEFORE ATTEMPTING TO OPERATE THE DRIVE.

1. THE CONNECTIONS OF THE TACHOMETER-FEEDBACK MODIFICATION SHOULD BE CHECKED AT THE TERMINAL BOARD, KIT, AND TACHOMETER TO MAKE SURE THEY ARE CONNECTED.
2. THE MOTOR FIELD SHOULD BE CHECKED TO MAKE SURE IT IS CONNECTED, AT THE MOTOR AND AT THE TERMINAL BOARD.
3. ANY OVERSPEED OR FIELD-LOSS PROTECTION, WHEN PROVIDED, SHOULD BE CONNECTED.

1. Turn the **IR COMP** potentiometer on the front of the unit to the extreme counter-clockwise position (**ZERO**).

2. Turn the **MAX SPEED** rheostat clockwise to the midpoint of its travel.

3. Turn the **TACH FEEDBACK** potentiometer on the tachometer-feedback unit to the extreme counter-clockwise position.

4. Set the **SPEED** potentiometer on the operator's stator to zero.

5. Depress and release the **START** pushbutton on the operator's station.

6. Adjust the **ZERO ADJ** potentiometer (located on the unit) so that the motor begins to rotate; then, "back off" the adjustment until the motor just turns over.

7. Turn the **SPEED** potentiometer on the operator's station to 100 percent speed.

8. Turn the **TACH FEEDBACK** potentiometer clockwise until the drive is running at the maximum speed required for the application. Drive speed may be measured directly by using a hand tachometer, or the a-c voltmeter may be connected across points 1TB(9, 10) in the power unit to obtain an indication of speed.

9. Depress and release the **STOP** pushbutton on the operator's station.

Proceed with the setup procedure on timed acceleration and current limit shown on Page 19. IR compensation procedure is not required since the **IR COMP** signal is not used with tachometer feedback. Make certain that the **IR comp pot** is turned fully **CCW**.

Follower Drives

NOTE

FOLLOW THIS PROCEDURE ONLY IF THE DRIVE IS TO BE USED AS A FOLLOWER (FOLLOWING AN EXTERNAL VOLTAGE SIGNAL).

1. Remove wire number 40 from the jog kit terminal board number 40. Cover the wire terminal with electrical tape to avoid any electrical contact between the wire and other components.

2. Calculate the value of the series resistor (if required — see page 12) and add it to the circuit (see page 18).

3. Connect the follower signal between points 1TB — 16 and 13(+) — see page 18.

4. Remove metal jumper from 2TB(4, 4A).

5. Follow the setup and adjustment procedure previously specified for either voltage-regulated or tachometer-feedback drives, as appropriate.

6. **Tracking Adjustment**

If the drive is too close follow the signal voltage, the following adjustments must be made for tracking.

a. Turn the **SPEED** control potentiometer to the **ZERO SPEED** position (Full **CCW**) and the **MAX SPEED** potentiometer to the 50% mark.

b. Apply the maximum follower signal voltage that will be encountered on this application.

c. Depress and release the START pushbutton.

d. Turn the SPEED control potentiometer slowly to the 100 percent speed position.

e. Adjust the MAX SPEED potentiometer for the required speed ratio between the master and GP-100 follower drives.

f. Cause the follower-signal voltage to be reduced to the minimum operating value expected on this application. This signal level should not require the SCR drive to operate below 1/20 rated speed.

g. Adjust the ZERO ADJ potentiometer on the conversion unit to establish the same speed ratio between the master (follower signal) and the SCR drive as existed with "full" follower signal.

h. Repeat steps (d) through (g) until satisfactory tracking is obtained.




Fig. 10. Conversion Unit with Cover
(230VAC, 15HP Unit Shown)




Fig. 11. Conversion Unit with Cover Removed
(230VAC, 15HP Unit Shown)

NOTE

THE MAIN AC LINE FUSES ARE MOUNTED ON THE CONVERSION UNIT FOR 230 VAC, 5-15 HP DRIVES, AND PANEL MOUNTED FOR ALL OTHER RATINGS.

OPERATION

NON-REVERSING DRIVES

Apply a-c power to the SCR drive by closing the a-c line disconnecting device (if used). Set the desired preset speed on the SPEED potentiometer on the operator's station. Depress and release the START pushbutton on the operator's station and the drive will accelerate to preset speed, either linearly with respect to time or under current limit, depending upon adjustments. Alternately, the SPEED potentiometer may be set initially at zero, the START button depressed and released, and the drive-speed controlled manually by the SPEED potentiometer during acceleration.

Depress and release the STOP pushbutton on the operator's station and the drive will coast to rest at a rate determined by the friction and inertia present in the drive system. If the dynamic-braking modification has been added, operation of the STOP pushbutton on the operator's station will cause the drive to rapidly brake to a stop.

Sudden, excessive overloads (300 percent) or d-c faults (shorts) will cause the static IOC circuit to stop the drive. Reset by pressing the STOP pushbutton; remove the condition causing the overload, and restart.

REVERSING DRIVES

Apply a-c power to the SCR drive by closing the a-c line disconnecting device (if used). Select the required direction of rotation with the FORWARD-REVERSE selector

switch. Set the desired preset speed on the SPEED potentiometer on the operator's station. Depress and release the START pushbutton on the operator's station and the drive will accelerate to preset speed, either linearly with respect to time or under current limit, depending upon adjustments. Alternately, the SPEED potentiometer may be set initially at zero, the START button depressed and released, and the drive-speed controlled manually by the SPEED potentiometer during acceleration.

If the FORWARD-REVERSE selector switch is operated with the drive running at preset speed, the drive will coast to rest, or dynamic brake to rest if this modification has been ordered. Depressing and releasing the START button will now cause the drive to accelerate to preset speed in the reverse direction.

If the START pushbutton is held depressed while operating the FORWARD-REVERSE selector, the faults (shorts) will cause the static IOC circuit to stop the drive. Reset by pressing the STOP pushbutton; remove condition causing overload and restart.

JOG

The operator's station will be equipped with a JOG-RUN selector switch. When this selector switch is in the JOG position, depressing and holding the START button will cause the drive to accelerate and run at a preset jog speed. The jog speed is set independently of the run speed by means of an internal potentiometer in the power unit.

TROUBLESHOOTING

GENERAL

Nearly all of the problems encountered in initial startup of adjustable-speed-drive equipments are caused by improper interconnection wiring. If difficulty is encountered, the first step should be a careful recheck of all interconnecting wiring in accordance with the Interconnection Chart, Table I, page 15.

In the event that this check does not disclose the problem, proceed to the Troubleshooting Chart, Table IV, performing each step in the sequence indicated.

WARNING

THIS EQUIPMENT IS AT LINE VOLTAGE ANY TIME AC POWER IS CONNECTED TO THE POWER UNIT, WHETHER THE EQUIPMENT IS IN OPERATION OR NOT IN OPERATION. ALL THREE PHASES OF THE AC POWER LINE MUST BE DISCONNECTED FROM THE POWER UNIT BEFORE IT IS SAFE TO TOUCH ANY INTERNAL PARTS OF THIS EQUIPMENT.

If the equipment operates, but operates improperly, refer to that portion of the Troubleshooting Chart titled "Operational Problems."

NOTE

DO NOT CHANGE ANY OF THE SETUP ADJUSTMENTS WITHOUT FIRST MAKING A NOTE OF THE SETTING SO THAT YOU CAN RETURN THE CONTROL TO THIS SETTING. THIS PROCEDURE WILL MINIMIZE TIME IN CORRECTING DIFFICULTY.

TABLE III VOLTAGE CHECK LIST

VAC CHECK LIST		
CIRCUIT	VOLTAGE -5%, +10%	MEASURE AT
AC INPUT	230 OR 460	L1, L2, L3
CR1 COIL	115	1TB(2, 24)
CR2 COIL	230	COIL OF CR2
F COIL	115	1TB(1, 24)
R COIL	115	1TB(5, 24)
J COIL	115	1TB(14, 24)
FAN SUPPLY	115	FTB(1, 3)

VDC CHECK LIST			
NOTE: 1TB13 AND 2TB5 ARE THE SYSTEM COMMON			
CIRCUIT	MEASURE AT	1/8 SPD DC VOLTS 230/460	RTD SPD DC VOLTS 230/460
MOT ARM	PTB(A1, A2)	40/80	240/500
MOT SH FLD	1TB(18, 19)	160/300	160/300
MOT SER FLD	PTB(S1, S2)	0.5-1.5	0.5-1.5
DRS	1TB(13, 18)	1-1.5	1-1.5
REFERENCE	1TB(7, 13)	1-2	14-18
SUPPLY	2TB(5-6)	20	20
TG OUT	1TB(13, 18)	2-3	15-25
LINEAR TIME PRECON- DITIONING	2TB(12, 5)	1-2	14-18
IOC (RESET)	2TB(13, 5)	20	20
IOC (TRIP)	2TB(13, 5)	2-3	2-3
AP (RELAY)	PTB(A1), 1TB(25)	PICKUP DROPOUT	20 6

TABLE IV TROUBLESHOOTING CHART

DRIVE DOES NOT OPERATE

Difficulty	Possible Cause	Remedy
1. No a-c power to power unit, points L1, L2 and L3.	Open disconnect, breaker, or fuse in a-c supply.	Locate and correct.
2. Blown fuse in power unit.	Shorts or grounds in wiring, open motor field circuit.	Correct wiring and replace fuse.
3. No d-c output from conversion unit (points P1-P2 on PTB).	D-c fault operating IOC circuit.	Remove fault and reset by pressing STOP button.
	No power-supply voltage 2TB (6, 5). No reference 2TB (7, 5).	Replace unit (see footnote). Check wiring to speed potentiometer and potentiometer itself. If a-c supply and reference are present, conversion unit is defective (see footnote).
	No a-c input.	See No. 1
4. No d-c output to motor (points A1-A2).	Series field not connected.	Connect series field or by-pass jumper of S1-S2 in power unit.
	<u>F</u> or <u>R</u> contactor inoperative.	Check for coil voltage at contactor. If voltage is present, replace defective contactor.
	CR relays inoperative.	Check for relay coil voltage. If voltage is present and relay inoperative, replace CR relay. If not voltage, check wiring to START-STOP pushbutton on operator's station.
	Blown fuse on control transformer	Check wiring and replace fuse.
5. Motor does not run.	Defective wiring.	Check armature and field wiring.
	No field supply (1TB 18-19). (Points S1-S2 not connected.)	Replace conversion unit (see footnote).
	Motor brushes not seated.	Free brushes in holder - see motor instructions.
	Defective motor.	Repair.

OPERATIONAL PROBLEMS

6. Motor will not reach top speed.	Improper setup.	Recheck tachometer-feedback setup.
	Low line voltage.	Correct.
	Motor overloaded.	Reduce load.

No attempt should be made to open or repair the sealed conversion unit. The conversion unit warranty becomes void if the unit has been opened or tampered with in any way (see WARRANTY). Defective conversion units or those which fail within the warranty period should be returned to the Company as indicated in the warranty instructions.

TABLE IV TROUBLESHOOTING CHART (CONT'D)

OPERATIONAL PROBLEMS (CONT'D)

Difficulty	Possible Cause	Remedy
6. Motor will not reach top speed. (Cont'd)	<p>Current limit set too low.</p> <p>Low reference voltage (2TB 7-5).</p> <p>High tachometer voltage (if used).</p> <p>Defective conversion unit.</p> <p>Zero adjust too low.</p> <p>Defective auxiliary contact on for contactor.</p>	<p>Recalibrate current limit.</p> <p>Should be approximately 10 to 15 volts with speed potentiometer full CW. If low, check for grounds and shorts.</p> <p>Check tachometer nameplate and setup procedure. Voltage from tachometer must not exceed 250V d-c.</p> <p>Replace. (see footnote)</p> <p>Readjust zero adjust.</p> <p>Replace contactor.</p>
7. Motor runs at top speed. Does not respond to speed potentiometer or has limited response.	<p>Improper setup.</p> <p>Motor wired incorrectly.</p> <p>Operator's station wired incorrectly.</p> <p>Tachometer signal (if used) is too low.</p> <p>Defective conversion unit.</p>	<p>Recheck.</p> <p>Recheck wiring.</p> <p>Check response of reference to speed potentiometer position.</p> <p>Check tachometer nameplate and review setup procedure.</p> <p>Replace. (see footnote)</p>
8. Motor jumps upon starting - will not run at low speed.	<p>Improper setup.</p> <p>Operator's station wired incorrectly.</p> <p>High breakaway torque required.</p> <p>Incorrect phase sequence.</p> <p>Defective conversion unit.</p>	<p>Recheck.</p> <p>Recheck wiring. Check response of reference to speed potentiometer position. Reduce if possible.</p> <p>Interchange any two a-c lines.</p> <p>Replace. (see footnote)</p>
9. Motor speed changes excessively when load is applied.	<p>Not balanced (firing).</p> <p>Improper setup.</p> <p>Low line voltage or excessive voltage regulation in a-x line.</p> <p>Motor overloaded.</p>	<p>Check 3-phase input for current balance.</p> <p>Recheck current limit and IR comp.</p> <p>Correct wire or transformer size.</p> <p>Reduce load.</p>

No attempt should be made to open or repair the sealed conversion unit. The conversion unit warranty becomes void if the unit has been opened or tampered with in any way (see WARRANTY). Defective conversion units or those which fail within the warranty period should be returned to the Company as indicated in the warranty instructions.

TABLE IV TROUBLESHOOTING CHART (CONT'D)

OPERATIONAL PROBLEMS (CONT'D)

Difficulty	Possible Cause	Remedy
9. Motor speed changes excessively when load is applied. (Cont'd)	Defective Conversion unit.	Replace. (see footnote)
	Excessive inertia	Reduce inertia (1) (See Page 8 - Specifications.)
10. Motor speed unstable.	Improper setup.	Check for too high IR comp (set at zero if tachometer generator is used).
	Excessive inertia.	Reduce inertia (1). (See Page 8 - Specifications.)
	Not balanced (firing).	Check 3-phase input for correct balance.
	Incorrect series field connections.	Check connections.
11. Motor overheats.	Motor overloaded.	See specifications and reduce load.
	Ambient temperature above 40 C (104 F).	Reduce temperature or improve ventilation.
	Motor ventilation restricted.	Remove restrictions.
	Defective motor.	Repair.
12. Motor noise excessive.	Loose motor mounting or coupling.	Tighten.
	Damaged bearing.	Replace bearing.
	Defective conversion unit.	Replace. (see footnote)
	Phase imbalanced.	Check 3-phase input for correct balance.
13. Motor sparks excessively (some sparking is normal).	Phase imbalanced.	Check 3-phase input for correct balance.
	Motor overloaded.	Reduce load.
	Brushes worn too short.	Replace. (see footnote)
	Rough commutator.	Repair.
	Defective conversion unit.	Replace.
14. Motor stops for no apparent reason. See No. 1, 2, 3, 4, 5.	Sudden extreme overload or intermittent d-c fault.	Remove cause of overload or fault and reset by pressing STOP button.
	Fuse blowing.	Replace fuse.

No attempt should be made to open or repair the sealed conversion unit. The conversion unit warranty becomes void if the unit has been opened or tampered with in any way (see WARRANTY). Defective conversion units or those which fail within the warranty period should be returned to the Company as indicated in the warranty instructions.

(1) When gears or belts are used, the inertia can be reduced by increasing the gear or belt ratio.

HOW THE SCR DRIVE WORKS

AC TO DC POWER CONVERSION

The power conversion circuit of the SCR drive consists of a three-phase, full-wave rectifier bridge (see Fig. 12). The negative legs of the rectifier bridge contain silicon-controlled rectifiers, while the positive legs contain diodes or uncontrolled rectifiers. The SCR conversion unit has a two-fold function; to rectify the a-c voltage to a d-c voltage, and to control the d-c voltage level.

A diode rectifier will conduct current in only one direction, blocking the voltage in the opposite direction. A rectifier bridge consisting of only diode rectifiers will convert an a-c voltage into a d-c voltage having an average value of 1.35 (for a three-phase bridge) times the rms value of the a-c voltage. The rectifiers block current flow in the reverse direction such that it is impossible to regenerate power back into the a-c line.

The function of controlling the d-c voltage level is obtained by using silicon-controlled rectifiers in the negative legs of the rectifier bridge. An SCR in a solid-state, semi-conductor which is basically a rectifier, but can also block voltage in the forward direction (anode positive with respect to cathode) until "fired" by a gate signal. It then switches to a highly conductive state having a very low forward voltage drop. The SCR remains in the conductive state even after the gate signal is removed, until the forward voltage is removed. It then reverts to a blocking state in the forward direction. The sinusoidal a-c voltage waveform satisfies these conditions in that each alternate half cycle causes the anode to swing positive with respect to the cathode to permit conduction, and the other half cycle reverses




Fig. 12. Rectifier Bridge Schematic

this voltage to turn the SCR off. A positive firing signal is applied to the gate of the SCR at the proper point in time to turn the SCR on. Controlling the point in time (with respect to the a-c supply voltage) when this gate signal is applied to the SCR controls the output voltage which can be obtained.

Figure 13 shows the output voltage and current waveform of a three-phase SCR conversion unit. It can be seen that as the firing pulses are advanced toward the zero time point, the average output voltage of the SCR conversion unit is increased.

An SCR has a minimum forward current level, called holding current, which is required for the SCR to stay in a conducting state. This means that the SCR conversion unit cannot be controlled if its output is open-circuited.

A diode rectifier, called a commutating or free-wheeling rectifier, is connected across the d-c terminals of the power-conversion bridge. This diode provides a free-wheeling path for current produced by the induced voltages in the d-c motor armature during phased-back operation. It prevents this free-wheeling current from flowing through a controlled-rectifier leg. If this were allowed, the SCR would fail to turn off when the supply voltage goes negative and control would be lost. The free-wheeling rectifier also acts to reduce motor-armature ripple current.




Fig. 13. Typical Waveforms

The conversion unit contains the silicon-controlled rectifiers, together with transient-voltage protective circuits. The SCRs and diodes are mounted on aluminum cooling fins. These fins serve to transmit the heat produced inside the rectifiers to the surrounding air. The conversion unit is convection cooled or force cooled depending on the horsepower rating of the drive.

Standard current-limiting fuses are placed in the a-c supply lines to the rectifier bridge.

Thyrectors* and other transient-voltage protective components are contained within the conversion unit. A Thyrector* is a special selenium rectifier which breaks down to limit high-voltage transients, similar to, but more sharply than, a Thyrite* resistor. It "passes" the energy of the transient-voltage rating of the SCRs and diodes. Series resistor-capacitor networks are connected in shunt across each SCR and the d-c output. These provide a low-impedance path parallel to the rectifier to further limit transient voltage spikes.

Noise suppression capacitors are connected across the gate to cathode of each SCR to prevent misfiring from extraneous signals.

SCR FIRING CIRCUIT

The firing circuits in the conversion unit provide pulses to the gate circuits of the three controlled rectifiers to "fire" them at the correct phase angle, as determined by the signal from the amplifier.

Each firing circuit consists of a pulse transformer, unijunction transistor, a capacitor, and a constant current supply. The firing circuit is controlled by a unijunction transistor. A unijunction is a special type of transistor that behaves similar to a switch; it is either full "on" or full "off". The unijunction transistor can be turned "on" by applying a voltage signal of sufficient magnitude to its input.

Operation of each of the three firing circuits is as follows: the amplifier determines the level of a constant current supply. The constant current linearly charges the capacitor, which is connected to the input of the unijunction transistor. When the voltage across the capacitor is large enough, the unijunction transistor turns "on". The

capacitor discharges through the unijunction transistor into the primary of the pulse transformer. The pulse of power is passed on to the secondary winding of the transformer which is coupled directly to the SCR gate circuit.

If the amplifier output is decreased, the magnitude of the constant current supply is reduced; the capacitor takes a longer time to charge, and the unijunction transistor turns on later in the cycle. Hence, the SCRs fire closer to the end of the cycle and the average d-c output voltage is decreased.

The firing circuits are synchronized with the a-c supply such that the firing pulses to the three SCRs are spaced 1/3 cycle apart. The SCRs will remain in the conducting state after the signal is removed, until the anode-to-cathode voltage is reversed.

MOTOR SHUNT FIELD EXCITATION

Excitation for the motor shunt field is obtained from a part of the full-wave rectifier bridge used to control the motor armature circuit.

The motor shunt field is connected between one a-c line and the positive side of the full-wave rectifier bridge. The positive side of this bridge contains three diode rectifiers. Two diode rectifiers furnish two-thirds power to the motor shunt field, while the other diode rectifier acts as a commutating or free-wheeling diode. This diode provides a free-wheeling path for the current produced by the induced voltages in the motor shunt field.

REGULATOR

Figure 14 is a block diagram of the SCR drive regulator. There are two feedback signals used in this regulator. The primary signal is from the d-c output voltage of the SCR conversion unit, and the second is an IR compensation signal. This IR compensation signal is obtained from the voltage drop across the armature resistor DRS, and is proportional to armature current. The magnitude of the compensation signal is established by the IR COMP potentiometer.

When these two feedback signals are combined, their difference is a measure of motor CEMF, which is very closely related to motor speed. Thus, the combination of these two signals provides a feedback which is a good approximation of motor speed.

* Trademark of the General Electric Company.

When this "net" feedback signal is compared to the regulator reference voltage, the resulting signal is called the error signal. The level of the error signal is very small and requires amplification (by the amplifier) before it can be used to control the firing circuit.

The output of the amplifier controls the value of current delivered by the constant current source in the firing circuit. As the error signal increases, the magnitude of the capacitor constant charging current increases. With a rapid charging rate, the capacitor is charged quickly and the firing pulse occurs early in the cycle. This results in turning the SCRs "on" at an earlier point in the a-c wave, increasing the average d-c output voltage.

TIMED ACCELERATION

The timed acceleration function is inserted between the preset reference voltage and the regulator reference as shown in Fig. 14. This function is inoperative except during acceleration or deceleration of the drive. When the START button is pressed, the F (or R) contactor applies the preset reference to the timed acceleration circuit. This circuit allows the regulator reference voltage to increase smoothly at a rate (2.5-10 seconds) established by the setting of the TIME ACCEL potentiometer.

The timed acceleration circuit consists essentially of a constant current source and a capacitor. When this current source is used to charge the capacitor, its voltage will increase approximately linearly with time. The voltage appearing on this capacitor is the regulator reference.

The total accelerating time is thus the charging time for the capacitor, and is determined by the setting of the TIME ACCEL potentiometer, which controls the value of capacitor voltage (regulator reference) is determined by the setting of the operator's SPEED potentiometer.

Whenever the preset reference is at a higher value than the regulator reference, the timing circuit becomes operative. If the value of preset reference is reduced below the regulator reference voltage (by turning the SPEED potentiometer down), the capacitor in the TIME ACCEL circuit will discharge at a fixed exponential rate, reducing the regulator reference voltage.

Under these conditions, the drive will decelerate to the new preset speed at this rate, assuming that this rate is slower than the normal coasting time of the drive and its connected load.

When the STOP button is pressed, the CR1 relay is de-energized and will discharge the capacitor in the TIME ACCEL circuit. This "resets" the circuit, assuring that the next start will find the reference voltage at zero.




Fig. 14. Regulator Block Diagram

CURRENT LIMIT

The current limit signal is obtained from the voltage across the DRS resistor. This voltage is proportional to the motor armature current. The magnitude of the current limit feedback signal is adjusted by the "CUR LIMIT" potentiometer.

When the armature current feedback signal increases to the limit setting, it acts to retard the charging rate of the capacitor in the firing circuit. The unijunction transistor fires later and the SCRs are phased back (turn on later in the cycle) until the armature current is reduced to the level determined by the setting of the CUR LIMIT potentiometer.

STATIC IOC CIRCUIT

A static instantaneous-overcurrent circuit senses armature current. When current exceeds approximately 300 percent, this circuit prevents the SCRs from firing and so reduces output voltage to zero in 1/3 cycle.

This circuit is reset by pressing the STOP button on the operator's station.

MAGNETIC FUNCTIONS

Depressing the START pushbutton energizes the CR1 relay which removes the current limit clamp and initiates the timed acceleration circuit (if not disabled by removal of jumper 4-4A on 2TB). The F (or R) contactor, also energized by the START pushbutton connects the motor-armature circuit to the conversion unit and applies preset reference voltage.

Depressing the STOP pushbutton drops out relay CR1 and the F (or R) contactor. Relay CR1 applies current limit and resets the timed acceleration circuit. The F (or R) contactor disconnects the motor-armature circuit from the conversion unit and removes the preset reference voltage.

Relay CR2 provides loss of phase protection (L1) by removing the 115 VAC control supply from the magnetic circuitry. Loss of phase protection for L2 and L3 is provided by the loss of excitation of the control power transformer (CPT).

When dynamic braking is furnished, the F (or R) contactor is used to connect the dynamic braking resistor to the motor armature.

On reversing drives, an anti-plugging relay, AP, is connected across the motor armature. Relay AP locks out the start circuit as long as the armature voltage is above 20 VDC for 230 VAC drives and 40 VDC for 460 VAC drives.

The jog selector switch actuates the jog relay and connects the jog reference to the regulator. It also disconnects the seal circuit(s) to the F (and R) contactor(s). Depressing the START pushbutton jogs the motor. Releasing the START pushbutton stops the motor.


TACHOMETER FEEDBACK MODIFICATION

The tachometer generator provides a voltage-feedback signal proportional to motor speed. This voltage-feedback signal is fed into a full-wave rectifier bridge which makes the feedback signal insensitive to the polarity of the tachometer-generator output voltage. A resistor bridge, located immediately after the full-wave rectifier bridge, reduces the tachometer-generator output voltage to a suitable value. The output of the resistor bridge is then fed to the regulator at points 1 and 5 on 2TB.

The armature-voltage feedback is disconnected by removing jumper (9 - 10) on 2TB, thus permitting the tachometer generator to control the drive. Since the tachometer generator provides an accurate speed signal, the IR comp circuit is not required and "IR COMP" is set to zero (CCW).

APPENDIX

DIMENSIONS



PWR UNIT SIZE	A	B	C RESISTOR CASE	APPROX WEIGHT (POUNDS)
W20	32.00	20.00	NO RESISTOR CASE	115 SEE NOTE No 3
W25	40.00	25.00	NO RESISTOR CASE	195 SEE NOTE No 3
W25X	40.00	25.00	6.50	220 SEE NOTE No 3

- 1 ALLOW AT LEAST 3 INCHES AT EACH SIDE OF ENCLOSURE FOR AIR EXHAUST AND AT LEAST 6 INCHES AT BOTTOM FOR AIR ENTRANCE.
- 2 DOOR HAS INTERNAL HINGES WITH REMOVABLE PINS.
- 3 WEIGHTS TABULATED MAY VARY $\pm 20\%$ DEPENDING UPON HORSEPOWER AND FUNCTIONS PROVIDED
- 4 VIEWS SHOW NEMA 1 (VENTILATED) GENERAL PURPOSE IN-DOOR ENCLOSURE
- 5 ALL DIMENSIONS ARE INCHES

Fig. 15 Power unit dimensions




Fig. 17 Speed indicator enclosure dimensions




Fig. 16 Speed indicator meter dimensions




Fig. 18 Operator's station dimensions




Fig. 19. Elementary Diagram — All Modifications Shown

- LEGEND**
- 1 - DEVICES MOUNTED IN OPERATOR'S STATION
 - * - TEMPERATURE SWITCH MOUNTED IN MOTOR
 - * - THERMAL SWITCH MOUNTED ON SCR HEATSINK
 - etc. - TERMINAL BOARD JUMPERS WITH REFERENCING NOTE NUMBER INSIDE
 - 1 2 3 etc. - WIRE NUMBERS
 - (1) (2) (A) etc. - COMPONENT TERMINAL NUMBERS
 - (1) (2) (3) etc. - TERMINAL BOARD POINTS
 - - STANDARD CONTROL CIRCUITS
 - - STANDARD POWER CIRCUITS
 - - OUTLINE OF POWER MODULE
 - - OPTIONAL MODIFICATIONS UNLESS OTHERWISE INDICATED

- NOTES**
- 1 WIRE NUMBER "10" MAY BE DESIGNATED AS "F" ON OLDER UNITS IS 18P 230VAC
 - 2 IF TIME ACCELERATION IS NOT DESIRED REMOVE JUMPER (POINT 2 TO 2 ON 17B)
 - 3 WHEN TACH FEEDBACK IS USED REMOVE JUMPER (POINT 2 TO 2 ON 17B)
 - 4 IF TEMPERATURE SWITCH IS PROVIDED REMOVE JUMPER (POINT 1 TO 12 ON 17B)
 - 5 6 REMOVE JUMPERS (POINT 1 TO 2 AND POINT 2 TO 3 ON 17B) FOR ALL REVERSING DRIVES
 - 7 CURRENT MAY BE MONITORED BY REMOVING JUMPER (POINT 2 TO 2 ON 17B) (RESISTANCE NOT PROVIDED)
 - 8 REPLACE JUMPER (POINT 15 TO 15 ON 17B) WITH MOTOR SERIES FIELD WHEN USED. THIS SERIES FIELD MAY BE WIRED IN AT THE MOTOR CONDUIT BOX FOR NON-REVERSING DRIVES ONLY
 - 9 REPLACE JUMPER (POINT 25 TO 20 ON 17B) WITH APR RE-SISTOR FOR 480VAC DRIVES
 - 10 CONNECT WIRE "W1" TO CRY POINT "X2" FOR 60WZ "X2" FOR 50WZ INPUT. VERIFY CR2 COMPATIBILITY WITH LINE #2 FOR ALL REVERSING DRIVES
 - 11 CONNECT WIRE "CR2" TO CRY POINT "X2" FOR 480VAC "X2" FOR 230VAC DRIVES
 - 12 SUPPLIED ONLY WITH REVERSING CIRCUITS
 - 13 STANDARD MOTOR ROTATION IS COUNTER CLOCKWISE LOOKING AT THE COMMUTATOR END
 - 14 REFER TO THE INSTRUCTION BOOK TEXT FOR DETAILED DC-302 SCR DRIVE
 - 15 REFER TO THE CONTACT FOR MATERIAL TO BE SUPPLIED BY THE GENERAL. SUCH MATERIAL IS NOT INCREASED BY ANYTHING SHOWN ON THE DRAWING

SPARE AND RENEWAL PARTS

TABLE V SPARE AND RENEWAL PARTS LIST

PART NAME	CATALOG NUMBER	PART QTY	230VAC SUPPLY							460VAC SUPPLY											
			DRIVE HP							DRIVE HP											
			5	7½	10	15	20	25	30	5	7½	10	15	20	25	30	40	50	60		
CONVERSION UNIT *	331X232AB ___		G01			G02		G03		G04			G05			G06					
CONTROL (CPT) TRANSFORMER	A = 104X156AA112		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
F CONTACTOR	A = 104X105XAG016 B = 104X105XBG016 C = 104X105XCG016		A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
DRS RESISTOR	A = 104X136AD001		1	1	1	1	1	2	2	2	1	1	1	1	1	1	2	2	2	1	1
CR1 RELAY	A = 104X166AA038		A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
CR2 RELAY	A = 104X127BB008 (use D14 for 50 HZ)		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
D.B RESISTOR	A = 104X135AA006 B = 104X135AA007 C = 104X135AA008 D = 104X135AD003 E = 104X136AD018		D	D	D	D	A	A	A	E	E	E	C	C	C	C	B	B	B		
CONTROL FUSE (CFU)	A = 104X109AA002		1	1	2	2	2	2	2	1	1	1	3	3	3	3	3	3	3	3	3
LINE FUSE **	A = 104X109AB005 B = 104X109AB006 C = 104X109AE007 D = 104X109AE008 E = 104X109AE015		A	A	A	A	A	A	A	C	C	C	D	D	D	D	E	E	E		
TACH FDBK KIT	A = 331X200AAG03		3	3	3	3	3	3	3	A	A	A	A	A	A	A	A	A	A	A	A
FAN KIT	A = 331X297AAG01		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
NON-REV OP STATION	A = 331X208ABG01 or G02 W/JOG						A	A	A				A	A	A	A	A	A	A	A	A
JOG RELAY	SEE CR1 RELAY		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
CHOKE ASM	A = 799C793AAG01						A	A	A										A	A	A
REVERSING OP STATION	A = 331X208ABG03 or G04 W/JOG						1	1	1										1	1	1
AP RELAY	A = 104X131AB003		A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
APR RESISTOR	A = 104X123AB014		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
R CONTACTOR	A = 104X105XAG016 B = 104X105XBG016 C = 104X105XCG016		A	A	B	B	C	C	C	A	A	A	B	B	B	B	C	C	C		
			1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

*See SCR drive Warranty for replacing "in-warranty" failure of power conversion units.

**Fuses not included in warranty (See warranty statement).

Order spare or renewal parts from your drive supplier or nearest General Electric sales office giving complete power unit nameplate data, parts quantity and catalog number from the above tabulation.

CAUTION

USE ONLY GE CLF CLASS H FUSES FOR 230VAC, 5-15HP.
USE BUSSMAN TYPE KAC FOR ALL OTHER DRIVES.

TABLE VI TRANSFORMER DATA

USE OF TABLE

Determine transformer connection diagram from this table based on drive HP and AC line voltage.
Do not use diagram on transformer nameplate.

Isolating Transformers

DRIVE HP	AC LINE VOLTS (1)	MODEL No (2)	ORDERING CAT No 104X218	KVA (4)	CONNECTION FIG No (3) (5)	APPROX DIMENSIONS (6)			APPROX WTS (LBS)
						H	W	D	
230 VAC - 240 VDC DRIVES									
5	230 460 575	9T48V2011G2 9T48V2012G2 9T48V2013G2	DD001 DD001 DE001	7.5	D	27.8	9.1	7.9	140
7 1/2	230 460 575	9T48V2021G2 9T48V2022G2 9T48V2023G2	DD002 DD002 DE002	11	D	31.9	9.1	7.9	194
10	230 460 575	9T48V2031G2 9T48V2032G2 9T48V2033G2	DD003 DD003 DE003	15	D	32.2	11.6	10.1	295
15	230 460 575	9T48V2041G2 9T48V2042G2 9T48V2043G2	DD004 DD004 DE004	20	D	38.2	11.6	10.1	383
20	230 460 575	9T48V2502G88 9T48V2502G88 9T48V2502G87	DD005 DD005 DE005	25	B	31.0	24.0	19.5	340
25	230 460 575	9T48V2504G88 9T48V2504G88 9T48V2504G87	DD006 DD006 DE006	30	B	31.0	24.0	19.5	350
30	230 460 575	9T48V2513G88 9T48V2513G88 9T48V2513G87	DD007 DD007 DE007	38	B	31.0	24.0	19.5	430
460 VAC - 500 VDC DRIVES									
5	230 460 575	9T48V2015G2 9T48V2016G2 9T48V2017G2	DF001 DR001 DX001	7.5	E	27.8	9.1	7.9	140
7 1/2	230 460 575	9T48V2025G2 9T48V2026G2 9T48V2027G2	DF002 DR002 DX002	11	D	31.9	9.1	7.9	194
10	230 460 575	9T48V2035G2 9T48V2036G2 9T48V2037G2	DF003 DR003 DX003	15	D	32.2	11.6	10.1	295
15	230 460 575	9T48V2045G2 9T48V2046G2 9T48V2047G2	DF004 DR004 DX004	20	D	38.2	11.6	10.1	383
20	230 460 575	9T48V2502G88 9T48V2502G88 9T48V2502G86	DF005 DR005 DX005	25	C	31.0	24.0	19.5	340
25	230 460 575	9T48V2504G88 9T48V2504G88 9T48V2504G86	DF006 DR006 DX006	30	B	31.0	24.0	19.5	350
30	230 460 575	9T48V2513G88 9T48V2513G88 9T48V2513G86	DF007 DR007 DX007	38	C	31.0	24.0	19.5	430
40	230 460 575	9T48V2516G88 9T48V2516G88 9T48V2516G86	DF008 DR008 DX008	50	B	31.0	24.0	19.5	450
50	230 460 575	9T48V2523G88 9T48V2523G88 9T48V2523G86	DF009 DR009 DX009	61	C	33.0	32.0	22.0	700
80	230 460 575	9T48V2526G88 9T48V2526G88 9T48V2526G86	DF010 DR010 DX010	82.5	C	33.0	32.0	22.0	750

Auto Transformers

DRIVE HP	AC LINE VOLTS (1)	MODEL No (2)	ORDERING CAT No 104X218	KVA (4)	CONNECTION FIG No (3) (5)	APPROX DIMENSIONS (6)			APPROX WTS (LBS)	
						H	W	D		
230 VAC - 240 VDC DRIVES										
5	460 575	9T21V6581 9T21V6583	AF001 AE001	7.5	A	24.3	25.4	7.2	6.3	81
7 1/2	460 575	9T21V6905 9T21V6921	AF002 AE002	11	A	27.4	26.8	7.2	6.3	106
10	460 575	9T21V6891 9T21V6893	AF003 AE003	15	A	27.8	26.8	9.1	7.9	140
15	460 575	9T21V6882 9T21V6894	AF004 AE004	20	A	28.9	31.9	9.1	7.9	155
20	460 575	9T21V6906 9T21V6917	AF005 AE005	25	A	32.9	32.2	9.1	7.9	207
25	460 575	9T21V6907 9T21V6918	AF006 AE006	30	A	32.2	34.2	11.6	10.1	285
30	460 575	9T21V6908 9T21V6919	AF007 AE007	36	A	34.2	38.2	11.6	10.1	336
460 VAC - 500 VDC DRIVES										
5	230 575	9T21V6581 9T21V6582	AF001 AR001	7.5	A	24.3	22.7	7.2	6.3	81
7 1/2	230 575	9T21V6905 9T21V6909	AF002 AR002	11	A	27.4	23.7	7.2	6.3	106
10	230 575	9T21V6891 9T21V6910	AF003 AR003	15	A	27.8	23.3	9.1	7.9	140
15	230 575	9T21V6892 9T21V6911	AF004 AR004	20	A	28.9	26.4	9.1	7.9	155
20	230 575	9T21V6906 9T21V6912	AF005 AR005	25	A	32.8	29.4	9.1	7.8	207
25	230 575	9T21V6907 9T21V6920	AF006 AR006	30	A	32.2	26.8	9.1	7.8	125
30	230 575	9T21V6908 9T21V6913	AF007 AR007	36	A	34.2	27.8	11.6	7.9	140
40	230 575	9T48V9182 9T21V6915	AF008 AR008	61	A	31.9	30.1	9.1	7.9	194
50	230 575	9T48V9182 9T21V6915	AF009 AR009	61	A	31.0	30.1	24.0	11.6	340
80	230 575	9T48V9183 9T21V6916	AF010 AR010	82.5	A	31.0	33.2	24.0	11.6	430

- (1) For other voltage ratings, refer to the company.
- (2) All models are 60 hertz only.
- (3) NEMA and ASA standard lead marking used. "H" leads are higher voltage leads, "X" leads are lower voltage leads.
- (4) KVA ratings shown are transformer ratings for the connection shown.
- (5) These connection diagrams, not those shown on transformer nameplates, must be used for SCR drives.
- (6) Mounting extension on wall-mounted transformers is included in the given dimensions.
- (7) Isolating transformers for 20 HP and above are floor mounted. All others are wall-mounted.




Fig. 20. Transformer Connection Diagrams

PHASE BALANCE ADJUSTMENT

The balance adjustment of the three firing circuits is performed at the factory and the rheostat shafts are sealed by means of a dab of glue. Normally, no further adjustment is required in the field; however, the following set-up procedure is recommended.

1. Connect the vertical input leads of a cathode-ray oscilloscope (CRO) across the DRS resistor, points P1 (+) and 13(-), to monitor armature current.* The voltage drop across this resistor is approximately 1-volt d-c at rated armature current.

2. Connect the drive to the a-c line.

3. Depress the START pushbutton.

4. Operate the drive at a high enough speed and load to give a display of the armature current on the CRO screen.

5. Start adjustment of the two balance rheostats from the CW position, and make small successive adjustments of each.

6. Adjust the two balance rheostats until all three phases are ON and all current peak amplitudes are of approximately the same magnitude (see Fig. 21).




Fig. 21. Oscilloscope trace after adjustment

PHASE BALANCE ADJUSTMENT WITH CLAMP-ON AMMETER (NO OSCILLOSCOPE AVAILABLE)

1. Operate the drive at half speed with normal working load.

2. Using the ammeter, measure each input phase to verify that the readings are within ± 1 ampere of each other (the positioning of the ammeter around each wire should be the same for accurate measurement). If measurements are not within ± 1 ampere, perform the adjustments in steps A and B.

A. Start adjustment of the three balance rheostats from the CW position and make small successive adjustments of each.

B. Adjust the three balance rheostats until all three phases are ON and all current amplitudes are of approximately the same magnitude.

* CAUTION

THE DRIVE IS CONNECTED DIRECTLY TO THE AC LINE, HENCE THE CRO (CHASSIS OR INPUT LEADS) MAY NOT NORMALLY BE GROUNDED. THIS MEANS THAT THERE WILL BE A VOLTAGE DIFFERENCE BETWEEN THE CRO CASE AND GROUND. IF THE CRO CHASSIS IS GROUNDED, CIRCULATING GROUND CURRENTS MAY DAMAGE THE DRIVE OR CRO.

THE CRO CHASSIS MAY BE GROUNDED ONLY IF A DIFFERENTIAL INPUT VERTICAL AMPLIFIER IS USED, OR IF THE DRIVE IS CONNECTED TO THE AC LINE THROUGH AN ISOLATION TRANSFORMER WHOSE SECONDARY WINDING IS UNGROUNDED.

NOTES

GENERAL ELECTRIC COMPANY — DIRECT CURRENT MOTOR & GENERATOR PRODUCTS DEPARTMENT
ERIE, PENNSYLVANIA 16531

GENERAL  **ELECTRIC**