



## INSTRUCTIONS

GEK-86677  
Insert Booklet GEK-7354

---

### DC AUXILIARY RELAY


TYPE HAA99AG

#### INTRODUCTION

This instruction book, together with insert booklet GEK-7354, forms the instructions for the HAA99AG relays.

The HAA99AG is similar to the HAA16B relay, except that there are two electrically separate, normally open contacts.

The internal connections are shown in Figure I of this instruction book.



VOLTS DC	OHMS		
	COIL	R1	R(EXT.)
250	95	350	1650
125	95	350	650
48	95	350	—

Figure I (0285A8973-0) Internal Connections Diagram for the HAA99AG Relay (Back View)