INSTRUCTIONS



VOLTAGE RELAY

TYPE IAV

MODEL 0156A2814

INTRODUCTION

These instructions plus those included in GEH-1814 form the instructions for model 0156A2814.

DESCRIPTION

The model 156A2814 is similar to the model 12IAV51D(-)A described in the attached booklet except that the seal-in unit is A.C. operated.

The 0.4 ampere element should pick up between 0.30 - 0.4 amperes (gradually applied) and be quiet up to 0.65 amperes. The 0.2 ampere element should pick up between 0.16 - 0.2 amperes and be quiet up to 0.30 amperes.

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

To the extent required the products described herein meet applicable ANSI, IEEE and NEMA standards; but no such assurance is given with respect to local codes and ordinances because they vary greatly.



GE Power Management

215 Anderson Avenue Markham, Ontario Canada L6E 1B3 Tel: (905) 294-6222 Fax: (905) 201-2098

www.GEindustrial.com/pm