



INSTRUCTIONS

GEK-49897
Insert Booklet GEI-33995

UNDervoltage RELAY

TYPE IAV99AD

INTRODUCTION

These instructions plus those included in GEI-33995 form the instructions for this relay.

DESCRIPTION

Model IAV99AD is similar to IAV74A described in GEI-33995 except that the IAV99AD has two circuit closing contacts (normally closed). The internal connection diagram for the IAV99AD relay is shown in Fig. 1 of this supplement.

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

To the extent required the products described herein meet applicable ANSI, IEEE and NEMA standards; but no such assurance is given with respect to local codes and ordinances because they vary greatly.

GENERAL  ELECTRIC




Fig. 1 (0275A2062-0) Internal Connection Diagram for 12IAV99AD